



Substrate Preparation

GENERAL REQUIREMENTS

All substrates to receive ArmourColor shall be sound, crack-free, dust-free, flat, and smooth (equivalent to a drywall level 5) and free of surface contaminants and defects.

For other substrates please contact Armourcoat USA.

Build quality is the responsibility of the General Contractor.

SA010708

RECOMMENDED SUBSTRATES

Drywall: To be prepared to a minimum of a Level 5.

Brick, Block, CMU, & Precast: Prepare as to receive a high-sheen paint coating (level 5).

Previously Painted: Test for bond and load bearing strength and prepare to conform to the general requirements (level 5). For glossy paints lightly sand surface to remove surface luster. This recommendation is for water-based paint systems only.

MDF Panels: Apply 2 coats of Sherwin Williams Preprime Wall & Wood Primer B49W2, or equivalent oil-based wood primer to all six sides of the panels and allow to dry. All MDF panels are to be at least 3/4" in thickness.

